

Element Selection Criteria

Element Selection Criteria

Overview

- Elements in ABAQUS
- Structural Elements (Shells and Beams) vs. Continuum Elements
- Modeling Bending Using Continuum Elements
- Stress Concentrations
- Contact
- Incompressible Materials
- Mesh Generation
- Solid Element Selection Summary

Elements in ABAQUS

- The wide range of elements in the ABAQUS element library provides flexibility in modeling different geometries and structures.
- Each element can be characterized by considering the following:
 - Family
 - Number of nodes
 - Degrees of freedom
 - Formulation
 - Integration


Elements in ABAQUS

- **Family**


- A family of finite elements is the broadest category used to classify elements.

- Elements in the same family share many basic features.


- There are many variations within a family.




continuum (solid elements)




shell elements




beam elements




rigid elements




membrane elements



infinite elements



special-purpose elements like springs, dashpots, and masses




truss elements

Elements in ABAQUS


- Number of nodes
(interpolation)

- An element's number of nodes determines how the nodal degrees of freedom will be interpolated over the domain of the element.
- ABAQUS includes elements with both first- and second-order interpolation.



CPE4

First-order
interpolation



CPE8

Second-order
interpolation

Elements in ABAQUS

- Degrees of freedom

- The primary variables that exist at the nodes of an element are the degrees of freedom in the finite element analysis.

- Examples of degrees of freedom are:

- Displacements

- Rotations

- Temperature

- Electrical potential

- Some elements have internal degrees of freedom that are not associated with the user-defined nodes.

Elements in ABAQUS

- **Formulation**

- The mathematical formulation used to describe the behavior of an element is another broad category that is used to classify elements.
- Examples of different element formulations:

Plane strain

Plane stress

Hybrid elements

Incompatible-mode elements

Small-strain shells

Finite-strain shells

Thick shells

Thin shells

Elements in ABAQUS

- **Integration**

- The stiffness and mass of an element are calculated numerically at sampling points called "integration points" within the element.
- The numerical algorithm used to integrate these variables influences how an element behaves.

Elements in ABAQUS





- ABAQUS includes elements with both "full" and "reduced" integration.

- **Full integration:**

- The minimum integration order required for exact integration of the strain energy for an undistorted element with linear material properties.

- **Reduced integration:**

- The integration rule that is one order less than the full integration rule.


	Full integration	Reduced integration
First-order interpolation		
Second-order interpolation		

Elements in ABAQUS


- Element naming conventions: examples




B21: **B**eam, **2-D**,
1st-order interpolation




S8RT: **S**hell, **8**-node,
Reduced integration,
Temperature



CAX8R: **C**ontinuum,
AXisymmetric, **8**-node,
Reduced integration



CPE8PH: **C**ontinuum,
Plane strain, **8**-node, **P**ore
pressure, **H**ybrid



DC3D4: **D**iffusion (heat
transfer), **C**ontinuum, **3-D**,
4-node



DC1D2E: **D**iffusion (heat
transfer), **C**ontinuum, **1-D**,
2-node, **E**lectrical

Elements in ABAQUS

- Comparing ABAQUS/Standard and ABAQUS/Explicit element libraries
 - Both programs have essentially the same element families: continuum, shell, beam, etc.
 - ABAQUS/Standard includes elements for many analysis types besides stress analysis: heat transfer, soils consolidation, acoustics, etc.
 - Acoustic elements are also available in ABAQUS/Explicit.
 - ABAQUS/Standard includes many more variations within each element family.
 - ABAQUS/Explicit includes mostly first-order integration elements.
 - Exceptions: second-order triangular and tetrahedral elements and second-order beam elements.
 - Many of the same general element selection guidelines apply to both programs.

Structural Elements (Shells and Beams) vs. Continuum Elements

- Continuum (solid) element models can be large and expensive, particularly in three-dimensional problems.
- If appropriate, structural elements (shells and beams) should be used for a more economical solution.
 - A structural element model typically requires far fewer elements than a comparable continuum element model.
- For structural elements to produce acceptable results, the shell thickness or the beam cross-section dimensions should be less than 1/10 of a typical global structural dimension, such as:
 - The distance between supports or point loads
 - The distance between gross changes in cross section
 - The wavelength of the highest vibration mode


Structural Elements (Shells and Beams) vs. Continuum Elements

- Shell elements


- Shell elements approximate a three-dimensional continuum with a surface model.

- Model bending and in-plane deformations efficiently.


- If a detailed analysis of a region is needed, a local three dimensional continuum model can be included using multi-point constraints or submodeling.



3-D continuum



surface model




shell model of a hemispherical dome subjected to a projectile impact

Structural Elements (Shells and Beams) vs. Continuum Elements

- Beam elements


- Beam elements approximate a three-dimensional continuum with a line model.
 - Model bending, torsion, and axial forces efficiently.
 - Many different cross-section shapes are available.
 - Cross-section properties can also be specified by providing engineering constants.



3-D continuum



line model




framed structure modeled using beam elements

Modeling Bending Using Continuum Elements

- Physical characteristics of pure bending

- This is the assumed behavior of the material that finite elements attempt to model.


- Plane cross-sections remain plane throughout the deformation.
- The axial strain ϵ_{xx} varies linearly through the thickness.
- The strain in the thickness direction ϵ_{yy} is zero if $\nu = 0$.
- No membrane shear strain.
 - Implies that lines parallel to the beam axis lie on a circular arc.



Modeling Bending Using Continuum Elements

- Modeling bending using second-order solid elements (CPE8, C3D20R, ...)

- Second-order full- and reduced-integration solid elements model bending accurately:
- The axial strain equals the change in length of the initially horizontal lines.
- The thickness strain is zero.
- The shear strain is zero.



Because the element edges can assume a curved shape, the angle between the deformed isoparametric lines remains equal to 90° (implies $\varepsilon_{xy} = 0$).


Modeling Bending Using Continuum Elements

- Modeling bending using first-order fully integrated solid elements (CPS4, CPE4, C3D8)

- These elements detect shear strains at the integration points.

- Nonphysical; present solely because of the element formulation used.

- Overly stiff behavior results from energy going into shearing the element rather than bending it (called "shear locking").




Because the element edges must remain straight, the angle between the deformed isoparametric lines is not equal to 90° (implies $\varepsilon_{xy} \neq 0$).

Do not use these elements in regions dominated by bending!

Modeling Bending Using Continuum Elements


- Modeling bending using first-order reduced-integration elements (CPE4R, ...)
- These elements eliminate shear locking.
- However, hourglassing is a concern when using these elements.
 - Only one integration point at the centroid.
 - A single element through the thickness does not detect strain in bending.
 - Deformation is a zero-energy mode (deformation but no strain; called "hourglassing").



Bending behavior for a single first-order reduced-integration element

Modeling Bending Using Continuum Elements


- Hourglassing can propagate easily through a mesh of first-order reduced-integration elements, causing unreliable results.
- Hourglassing is not a problem if you use multiple elements—at least four through the thickness.
 - Each element captures either compressive or tensile axial strains but not both.
 - The axial strains are measured correctly.
 - The thickness and shear strains are zero.
 - Cheap and effective elements.



Modeling Bending Using Continuum Elements

- Detecting and controlling hourglassing


- Hourglassing can usually be seen in deformed shape plots.
 - Example: Coarse and medium meshes of a simply supported beam with a center point load.
- ABAQUS has built-in hourglass controls that limit the problems caused by hourglassing.
 - Verify that the artificial energy used to control hourglassing is small (<1%) relative to the internal energy.




Same load and displacement
magnification (1000×)

Modeling Bending Using Continuum Elements

- Use the X-Y plotting capability in ABAQUS/Viewer to compare the energies graphically.



Two elements through the thickness: Ratio of artificial to internal energy is 2%





Four elements through the thickness: Ratio of artificial to internal energy is 0.1%

Modeling Bending Using Continuum Elements


- Modeling bending using incompatible mode elements (CPS4I, ...)
 - Perhaps the most cost-effective solid continuum elements for bending dominated problems.
 - Compromise in cost between the first- and second-order reduced integration elements, with many of the advantages of both.
 - Model shear behavior correctly—no shear strains in pure bending.
 - Model bending with only one element through the thickness.
 - No hourglass modes, and work well in plasticity and contact problems.
 - The advantages over reduced-integration first-order elements are reduced if the elements are severely distorted; however, all elements perform less accurately if severely distorted.

Modeling Bending Using Continuum Elements

- Example: Cantilever beam with distorted elements



Parallel distortion



Trapezoidal distortion

Modeling Bending Using Continuum Elements

- Summary


Element type	ϵ_{xx}	ϵ_{yy}	ϵ_{xy}	Notes
Physical behavior	$\neq 0$	0	0	
Second-order	$\neq 0$	0	0	OK
First-order, full integration	$\neq 0$	$\neq 0$	$\neq 0$	Shear locking
First-order, reduced integration	0	0	0	Hourglassing if too few elements through thickness
	$\neq 0$	0	0	OK if enough elements through the thickness
Incompatible mode	$\neq 0$	0	0	OK if not overly distorted

Stress Concentrations


- Second-order elements clearly outperform first-order elements in problems with stress concentrations and are ideally suited for the analysis of (stationary) cracks.
 - Both fully integrated and reduced-integration elements work well.
 - Reduced-integration elements tend to be somewhat more efficient—results are often as good or better than full integration at lower computational cost.

Stress Concentrations


- Second-order elements capture geometric features, such as curved edges, with fewer elements than first-order elements.



Physical model





Model with first-order elements—element faces are straight line segments



Model with second-order elements—element faces are quadratic curves


Stress Concentrations

- Both first- and second-order quads and bricks become less accurate when their initial shape is distorted.
 - First-order elements are known to be less sensitive to distortion than secondorder elements and, thus, are a better choice in problems where significant mesh distortion is expected.
- Second-order triangles and tetrahedra are less sensitive to initial element shape than most other elements; however, wellshaped elements provide better results.



Stress Concentrations

- A typical stress concentration problem, a NAFEMS benchmark problem, is shown at right. The analysis results obtained with different element types follow.




Stress Concentrations

- First-order elements (including incompatible mode elements) are relatively poor in the study of stress concentration problems.


Element type	σ_{yy} at D (Target=100.0)	
	Coarse mesh	Fine mesh
CPS3 	55.06	76.87
CPS4 	71.98	91.2
CPS4I 	63.45	84.37
CPS4R 	43.67	60.6
CPS6 	96.12	101.4
CPS8 	91.2	100.12
CPS8R 	92.56	97.16

Stress Concentrations

- Second-order elements such as CPS6, CPS8, and CPS8R give much better results.
- Well-shaped, second-order, reduced-integration quadrilaterals and hexahedra can provide high accuracy in stress concentration regions.
 - Distorted elements reduce the accuracy in these regions.



Distortion in low strain gradient area





Distortion in high strain gradient area

Contact

- Almost all element types are formulated to work well in contact problems, with the following exceptions:

- Second-order quad/hex elements
- "Regular" second-order tri/tet (as opposed to "modified" tri/tet elements whose names end with the letter "M"), second-order wedge, and 6- node shell and membrane elements.



For the second-order tet, wedge, and 6-node shell and membrane elements, the directions of the consistent nodal forces resulting from a pressure load are not uniform with "classical" hard contact; use penalty-based contact instead.


- Convergence difficulties may arise with these elements.

Incompressible Materials

• Many nonlinear problems involve incompressible materials ($\nu = 0.5$) and nearly incompressible materials ($\nu > 0.475$).

- Rubber
- Metals at large plastic strains

- Conventional finite element meshes often exhibit overly stiff behavior due to volumetric locking, which is most severe when these materials are highly confined.



Example of the effect of volumetric locking

Incompressible Materials

- For an incompressible material each integration point's volume must remain almost constant. This overconstrains the kinematically admissible displacement field and causes volumetric locking
 - For example, in a refined three-dimensional mesh of 8-node hexahedra, there is—on average—1 node with 3 degrees of freedom per element.
 - The volume at each integration point must remain fixed.
 - Fully integrated hexahedra use 8 integration points per element; thus, in this example, we have as many as 8 constraints per element, but only 3 degrees of freedom are available to satisfy these constraints.
 - The mesh is overconstrained—it “locks.”
- Volumetric locking is most pronounced in fully integrated elements.
- Reduced-integration elements have fewer volumetric constraints.
 - Reduced integration effectively eliminates volumetric locking in many problems with nearly incompressible material.

Incompressible Materials


- Fully incompressible materials modeled with solid elements must use the "hybrid" formulation (elements whose names end with the letter "H").
 - In this formulation the pressure stress is treated as an independently interpolated basic solution variable, coupled to the displacement solution through the constitutive theory.
 - Hybrid elements introduce more variables into the problem to alleviate the volumetric locking problem. The extra variables also make them more expensive.
 - The ABAQUS element library includes hybrid versions of all continuum elements (except plane stress elements, where this is not needed).

Incompressible Materials

- Hybrid elements are only necessary for:
 - All meshes with strictly incompressible materials, such as rubber.
 - Refined meshes of reduced-integration elements that still show volumetric locking problems. Such problems are possible with elasticplastic materials strained far into the plastic range.
- Even with hybrid elements a mesh of first-order triangles and tetrahedra is overconstrained when modeling fully incompressible materials. Hence, these elements are recommended only for use as "fillers" in quadrilateral or brick-type meshes with such material.


Mesh Generation

- Elements are generated in the Mesh module of ABAQUS/CAE.
- Meshes containing the element shapes shown at right can be generated.
- Most elements in ABAQUS are topologically equivalent to these shapes.
 - For example, CPE4 (stress), DC2D4 (heat transfer), and AC2D4 (acoustics) are topologically equivalent to a linear quadrilateral.



Mesh Generation

- Quad/hex vs. tri/tet elements
- Of particular importance when generating a mesh is the decision regarding whether to use quad/hex or tri/tet elements.
- Quad/hex elements should be used wherever possible.
- They give the best results for the minimum cost.
- When modeling complex geometries, however, the analyst often has little choice but to mesh with triangular and tetrahedral elements.




Turbine blade with platform modeled with tetrahedral elements

Mesh Generation

- First-order tri/tet elements (CPE3, CPS3, CAX3, C3D4, C3D6) are poor elements; they have the following problems:
 - Poor convergence rate.
 - They typically require very fine meshes to produce good results.
 - Volumetric locking with incompressible or nearly incompressible materials, even using the "hybrid" formulation.
- These elements should be used only as fillers in regions far from any areas where accurate results are needed.

Mesh Generation

- "Regular" second-order tet, second-order wedge, and 6-node shell and membrane elements (C3D10, C3D15, STRI65, M3D6) should not be used to model contact unless a penalty-based contact formulation is used.
 - Under uniform pressure the contact forces are significantly different at the corner and midside nodes with "classical" hard contact.
- Second-order triangles (CAX6, CPE6, CPS6) may show a noisy contact distribution and may cause convergence difficulties.



Equivalent nodal forces created by uniform pressure on the face of a regular second-order tetrahedral element (C3D10) with "classical" hard contact

Mesh Generation

- Modified second-order tri/tet elements (C3D10M, etc.) alleviate the problems of other tri/tet elements.
 - Good convergence rate—close to convergence rate of second-order quad/hex elements.
 - Minimal shear or volumetric locking.
 - Can be used to model incompressible or nearly incompressible materials in the hybrid formulation (C3D10MH).
 - These elements are robust during finite deformation.
 - Uniform contact pressure allows these elements to model contact accurately.

Mesh Generation

- Mesh refinement and convergence

- Use a sufficiently refined mesh to ensure that the results from your ABAQUS simulation are adequate.
 - Coarse meshes tend to yield inaccurate results.
 - The computer resources required to run your job increase with the level of mesh refinement.
- It is rarely necessary to use a uniformly refined mesh throughout the structure being analyzed.
 - Use a fine mesh only in areas of high gradients and a coarser mesh in areas of low gradients.
- Can often predict regions of high gradients before generating the mesh.
 - Use hand calculations, experience, etc.
 - Alternatively, you can use coarse mesh results to identify high gradient regions.

Mesh Generation

– Some recommendations:

- Minimize mesh distortion as much as possible.
- A minimum of four quadratic elements per 90° should be used around a circular hole.
- A minimum of four elements should be used through the thickness of a structure if first-order, reduced integration solid elements are used to model bending.
- Other guidelines can be developed based on experience with a given class of problem.

Mesh Generation

- It is good practice to perform a mesh convergence study.
 - Simulate the problem using progressively finer meshes, and compare the results.
 - The mesh density can be changed very easily using ABAQUS/CAE since the definition of the analysis model is based on the geometry of the structure.
 - This will be discussed further in the next lecture.
 - When two meshes yield nearly identical results, the results are said to have "converged."
 - This provides increased confidence in your results.

Solid Element Selection Summary

Class of problem	Best element	choice Avoid using
General contact between deformable bodies	First-order quad/hex	Second-order quad/hex
Contact with bending	Incompatible mode	First-order fully integrated quad/hex or second-order quad/hex
Bending (no contact)	Second-order quad/hex	First-order fully integrated quad/hex
Stress concentration	Second-order	First-order
Nearly incompressible ($\nu > 0.475$ or large strain plasticity $e_{pl} > 10\%$)	First-order elements or second-order reduced integration elements	Second-order fully integrated

Solid Element Selection Summary

Class of problem	Best element	choice Avoid using
Completely incompressible (rubber $\nu = 0.5$)	Hybrid quad/hex, first-order if large deformations are anticipated	
Bulk metal forming (high mesh distortion)	First-order reduced integration quad/hex	Second-order quad/hex
Complicated model geometry (linear material, no contact)	Second-order quad/hex if possible (if not overly distorted) or second-order tet/tri (because of meshing difficulties)	
Complicated model geometry (nonlinear problem or contact)	First-order quad/hex if possible (if not overly distorted) or modified second-order tet/tri (because of meshing difficulties)	
Natural frequency (linear dynamics)	Second-order	Second-order fully integrated
Nonlinear dynamic (impact)	First-order	Second-order